

3BUILT MOTORSPORTS / HELIOSURE END USER AGREEMENT

NOTICE TO USER: PLEASE READ THIS AGREEMENT CAREFULLY. BY INSTALLING AND/OR USING ALL OR ANY PORTION OF THIS PRODUCT YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT ; WARRANTY IN SECTION 3; LIABILITY IN SECTION 5. YOU AGREE THAT THIS AGREEMENT IS LIKE ANY WRITTEN NEGOTIATED AGREEMENT SIGNED BY YOU. THIS AGREEMENT IS ENFORCEABLE AGAINST YOU AND ANY LEGAL ENTITY THAT OBTAINED THE PRODUCT AND ON WHOSE BEHALF IT IS USED.

IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT OR ARE UNDER 18 YEARS OLD, DO NOT INSTALL OR USE THIS PRODUCT. RETURN UNUSED PRODUCT WITHIN TEN (10) DAYS OF PURCHASE FOR A FULL REFUND OF PURCHASE PRICE. VISIT [HTTP://WWW.HELIOSURE.COM](http://www.heliosure.com) OR E-MAIL SALES@HELIOSURE.COM FOR REFUND INFORMATION.

1. DEFINITIONS

- a. "3Built Motorsports", a California Sole Proprietorship, 7622 Farmdale Ave., North Hollywood, Ca. 91605.
- b. "Heliosure" is 3Built Motorsports
- c. "Product" means any item sold 3Built Motorsports.
- d. "Documentation" means the Installation and Use Instructions or other paperwork sent with the Product.

2. FUNCTIONALITY AND RANGE. Some items are radio frequency controlled devices. They are susceptible to radio frequency interference. The control signal is encoded to reduce the possibility of interference, but it cannot be eliminated. The interference may cause the Product not to function as stated or desired. This may include non-operation, decreased range, and accidental activation of the Product.

3. LIMITED WARRANTY. 3Built Motorsports warrants to the individual or entity that first purchases the Product pursuant to the terms of this agreement that the Product will perform substantially in accordance with the Documentation for the sixty (60) day period following receipt of the Product when used as directed in the Documentation. Non-substantial variation of performance from the Documentation does not establish a warranty right. THIS LIMITED WARRANTY DOES NOT APPLY TO IMPROPERLY INSTALLED, ALTERED OR ABUSED PRODUCT. All warranty claims must be made, along with proof of purchase, within such sixty (60) day period. If the Product does not perform substantially in accordance with the Documentation, the entire liability of 3Built Motorsports and its affiliates and your exclusive remedy will be limited to either, at 3Built Motorsports' option, replacement of the Product or refund of the purchase price paid for the Product. THE LIMITED WARRANTY SET FORTH IN THIS SECTION GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE ADDITIONAL RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

4. DISCLAIMER. THE FOREGOING LIMITED WARRANTY IS THE ONLY WARRANTY MADE BY 3BUILT MOTORSPORTS AND ITS AFFILIATES AND STATES THE SOLE AND EXCLUSIVE REMEDIES FOR 3BUILT MOTORSPORTS, ITS AFFILIATES OR SUPPLIERS' BREACH OF WARRANTY. EXCEPT FOR THE FOREGOING LIMITED WARRANTY AND ANY WARRANTY, CONDITION, REPRESENTATION OR TERM TO THE EXTENT THE SAME CANNOT OR MAY NOT BE EXCLUDED OR LIMITED BY LAW APPLICABLE TO YOU IN YOUR JURISDICTION, 3BUILT MOTORSPORTS AND ITS AFFILIATES AND SUPPLIERS PROVIDE THE PRODUCT *AS-IS* AND *WITH ALL FAULTS* AND EXPRESSLY DISCLAIM ALL OTHER WARRANTIES, CONDITION, REPRESENTATIONS OR TERMS, EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE AS TO ANY MATTER, INCLUDING BUT NOT LIMITED TO PERFORMANCE, SECURITY, NON-INFRINGEMENT OF THIRD PARTY RIGHTS, INTEGRATION, MERCHANTABILITY, QUIET ENJOYMENT, SATISFACTORY QUALITY OR FITNESS FOR ANY PARTICULAR PURPOSE. The provisions of Sections 4 and Section 5 will survive the termination of this agreement, howsoever caused, but this will not imply or create any continued right to use the Product after termination of this Agreement.

5. **LIMITATION OF LIABILITY.** EXCEPT FOR THE EXCLUSIVE REMEDY SET FORTH ABOVE AND AS OTHERWISE PROVIDED IN SECTION 3, IN NO EVENT WILL 3BUILT MOTORSPORTS OR ITS AFFILIATES OR SUPPLIERS BE LIABLE TO YOU FOR ANY LOSS, DAMAGES, CLAIMS OR COSTS WHATSOEVER INCLUDING ANY CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES, ANY LOST PROFITS OR LOST SAVINGS, ANY DAMAGES RESULTING FROM BUSINESS INTERRUPTION, PERSONAL INJURY OR FAILURE TO MEET ANY DUTY OF CARE, OR CLAIMS BY A THIRD PARTY, EVEN IF A 3BUILT REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS, DAMAGES, CLAIMS OR COSTS. THE FOREGOING LIMITATIONS AND EXCLUSIONS APPLY TO THE EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION. 3BUILT MOTORSPORTS' AGGREGATE LIABILITY AND THAT OF ITS AFFILIATES AND SUPPLIERS UNDER OR IN CONNECTION WITH THIS AGREEMENT WILL BE LIMITED TO THE AMOUNT PAID FOR THE PRODUCT, IF ANY. THIS LIMITATION WILL APPLY EVEN IN THE EVENT OF A FUNDAMENTAL OR MATERIAL BREACH OR A BREACH OF THE FUNDAMENTAL OR MATERIAL TERMS OF THIS AGREEMENT.
6. **INDEMNITY.** You agree to hold 3Built Motorsports harmless from any and all liabilities, losses, actions, damages, or claims (including all reasonable expenses, costs, and attorneys fees) arising out of or relating to any use of, or reliance on, the Product, including, without limitation reliance on a) batteries, b) range, c) installation, d) performance, and e) failure to exercise reasonable judgment. Nothing contained in this agreement limits 3Built Motorsports' liability to you in the event of death or personal injury resulting from 3Built Motorsports' negligence or for the tort of deceit (fraud). 3Built Motorsports is acting on behalf of its affiliates and suppliers for the purpose of disclaiming, excluding and limiting obligations, warranties and liability, but in no other respects and for no other purpose.
7. **GOVERNING LAW.** This agreement will be governed by and construed in accordance with the substantive laws in force in the State of California, if the Product is purchased when you are in the United States, Canada, or Mexico.
8. **GENERAL PROVISIONS.** If any part of this agreement is found void and unenforceable, it will not affect the validity of the balance of this agreement, which will remain valid and enforceable according to its terms. This agreement will not prejudice the statutory rights of any party dealing as a consumer. This agreement may only be modified by a writing signed by an authorized member of 3Built Motorsports. This is the entire agreement between 3Built Motorsports and you relating to the Product and it supercedes any prior representations, discussions, undertakings, communications, or advertising relating to the Product.




SHOCK BLEEDER INSTALLATION INSTRUCTIONS

BY INSTALLING OR USING THIS PRODUCT YOU AGREE TO OUR “END USER AGREEMENT”.
IT IS INCLUDED WITH THESE INSTRUCTIONS.

PLEASE BE SURE TO READ THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE USING THE SHOCK BLEEDER

INCLUDED PARTS

- (1) Assembled Shock Bleeder with pressure guage, safety valve, splash guard, 2-way valve, & hose cap
- (1) Air compressor line adapter: has **Orange** release ring; Use on **Red** hose.
- (1) Vacuum pump adapter: has **Blue** release ring; Use on **Blue** hose.
- (1) KTM Shock adapter: has **Black** release ring; Use on **Clear** hose.



ADDITIONAL PARTS REQUIRED BUT NOT INCLUDED WITH THIS KIT

- (1) Air compressor
- (1) Air compressor quick connect fitting for your air compressor hose
- (1) Vacuum pump

Please watch our video at: <https://heliosure.com/sbvideo/>

SET-UP

- 1) Remove the three adapters from the bag and identify them via the Release Ring color (shown above).
- 2) Attach the Air Compressor adapter (1/4 NPT, **Orange** release ring) to your quick connect fitting for your air compressor hose.
- 3) Connect the Shock Bleeder's **Red** hose to the Air Compressor Adapter by pushing the hose all the way into the adapter and then slightly pulling back out without depressing the release ring. This will lock the hose.
- 4) Attach the Vacuum Pump Adapter (1/8 universal pipe thread, **Blue** release ring) to your vacuum pump. Use some thread sealing compound to ensure a good seal.
- 5) Connect the Shock Bleeder's **Blue** hose to the Vacuum Pump Adapter by pushing the hose all the way into the adapter and then slightly pulling back out without depressing the lock ring. This will lock the hose.
- 6) Make sure the Shock Bleeder is always vertical. The purple reservoir pointing up. There is an optional mounting plate available separately. If using your own bracket, use #10 x 3/4" screws for plastic or wood to attach to the main body (white colored).
- 7) **VERY IMPORTANT!** Set your compressor's pressure regulator to **45psi**. Do not connect the Red hose to your compressor at this time.

FILL THE RESERVOIR

- 1) Set the 2-way valve handle to the center position. (Half way between the Red hose and Blue hose.)
- 2) Remove the cap on the Clear hose and insert the hose into your shock oil container.
- 3) Turn on your vacuum pump.
- 4) Slowly turn the 2-way valve handle to the Vacuum position (Blue). The oil will start filling the reservoir.
- 5) Return the 2-way valve handle to the center position before all of the oil is drained from the shock oil container. There will still be residual vacuum in the reservoir. If you pull in a lot of air, the oil in the reservoir may splash and be sucked into the vacuum pump. Going slow is the key.
- 6) You can fill the reservoir with a maximum of 1 liter (1000cc) of shock oil.
- 7) When finished place the Black cap back onto the Clear hose. It will keep the oil from draining out.
- 8) Turn off your vacuum pump.

USE

- 1) Set your compressor's pressure regulator to **45psi**.
- 2) Connect the Red hose to your air compressor.
- 3) Install the Shock Adapter into your shock. Use a 4mm hex key to tighten the adapter.
- 4) Remove the black cap and connect the Clear hose to the Shock Adapter.
- 5) Turn on your vacuum pump.
- 6) Slowly turn the handle on the 2-way valve to the Vacuum (Blue) position. When the shock is empty of air, the gauge will read near -30 inHg (Maximum vacuum is pump dependent. Units are in inches of mercury.)
- 7) The shock shaft will retract. Wait a couple of minutes to be sure the shock is empty.
- 8) Turn the 2-way valve handle to the center position and then slowly to the Pressure position (Red). Oil will begin to flow into the shock.
- 9) The shock shaft will extend and pressure will build up to 45psi.
- 10) After 30 seconds slowly move the 2-way valve handle back to Vacuum (Blue).
- 11) The shock shaft will retract. Wait a couple of minutes to be sure the shock is empty.
- 12) Turn the 2-way valve handle to the center position and then slowly to the Pressure position (Red). Oil will begin to flow into the shock.
- 13) The shock shaft will extend and pressure will build up to 45psi.
- 14) Turn the 2-way valve handle back to the center position.
- 15) Disconnect the air compressor hose.
- 16) Turn the 2-way valve handle back to the Pressure side (Red) to equalize any pressure inside the shock bleeder reservoir and shock.
- 17) Adjust your WP shock reservoir piston, if necessary. Watch our video if you need more information.
<https://heliosure.com/sbvideo/>
- 18) Remove the Clear hose from the Shock Adapter. Place rags under shock as some oil may drip out.
- 19) Place the Black cap back onto the Clear hose.
- 20) Remove the Shock Adapter from the shock with the 4mm hex key.
- 21) Install the shock's fill hose port plug.

SALES AND TECHNICAL SUPPORT E-MAIL: sales@heliosure.com

These instructions are subject to change without notice.

www.heliosure.com
3Built Motorsports
North Hollywood, CA 91605