

HELIOSURE / 3BUILT MOTORSPORTS END USER AGREEMENT

NOTICE TO USER: PLEASE READ THIS AGREEMENT CAREFULLY. BY INSTALLING AND/OR USING ALL OR ANY PORTION OF THIS PRODUCT YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT; WARRANTY IN SECTION 3; LIABILITY IN SECTION 5. YOU AGREE THAT THIS AGREEMENT IS LIKE ANY WRITTEN NEGOTIATED AGREEMENT SIGNED BY YOU. THIS AGREEMENT IS ENFORCEABLE AGAINST YOU AND ANY LEGAL ENTITY THAT OBTAINED THE PRODUCT AND ON WHOSE BEHALF IT IS USED.

IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT OR ARE UNDER 18 YEARS OLD, DO NOT INSTALL OR USE THIS PRODUCT. RETURN UNUSED PRODUCT WITHIN TEN (10) DAYS OF PURCHASE FOR A FULL REFUND OF PURCHASE PRICE. VISIT [HTTP://WWW.HELIOSURE.COM](http://www.heliosure.com) OR E-MAIL SALES@HELIOSURE.COM FOR REFUND INFORMATION.

1. DEFINITIONS
 - a. "3Built Motorsports", a California Sole Proprietorship, 7622 Farmdale Ave., North Hollywood, Ca. 91605.
 - b. "Heliosure" is 3Built Motorsports
 - c. "Product" means any item sold 3Built Motorsports and/or Heliosure.
 - d. "Documentation" means the Installation Instructions or other paperwork sent with the Product.
2. FUNCTIONALITY AND RANGE. Some Products are radio frequency controlled devices. They are susceptible to radio frequency interference. The control signal is encoded to reduce the possibility of interference, but it cannot be eliminated. The interference may cause the Product not to function as stated or desired. This may include non-operation, decreased range, and accidental activation of the Product.
3. LIMITED WARRANTY. 3Built Motorsports warrants to the individual or entity that first purchases the Product pursuant to the terms of this agreement that the Product will perform substantially in accordance with the Documentation for the sixty (60) day period following receipt of the Product when used as directed in the Documentation. Non-substantial variation of performance from the Documentation does not establish a warranty right. THIS LIMITED WARRANTY DOES NOT APPLY TO IMPROPERLY INSTALLED, ALTERED OR ABUSED PRODUCT. All warranty claims must be made, along with proof of purchase, within such sixty (60) day period. If the Product does not perform substantially in accordance with the Documentation, the entire liability of 3Built Motorsports and its affiliates and your exclusive remedy will be limited to either, at 3Built Motorsports' option, replacement of the Product or refund of the purchase price paid for the Product. THE LIMITED WARRANTY SET FORTH IN THIS SECTION GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE ADDITIONAL RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.
4. DISCLAIMER. THE FOREGOING LIMITED WARRANTY IS THE ONLY WARRANTY MADE BY 3BUILT MOTORSPORTS AND ITS AFFILIATES AND STATES THE SOLE AND EXCLUSIVE REMEDIES FOR 3BUILT MOTORSPORTS, ITS AFFILIATES OR SUPPLIERS' BREACH OF WARRANTY. EXCEPT FOR THE FOREGOING LIMITED WARRANTY AND ANY WARRANTY, CONDITION, REPRESENTATION OR TERM TO THE EXTENT THE SAME CANNOT OR MAY NOT BE EXCLUDED OR LIMITED BY LAW APPLICABLE TO YOU IN YOUR JURISDICTION, 3BUILT MOTORSPORTS AND ITS AFFILIATES AND SUPPLIERS PROVIDE THE PRODUCT *AS-IS* AND *WITH ALL FAULTS* AND EXPRESSLY DISCLAIM ALL OTHER WARRANTIES, CONDITION, REPRESENTATIONS OR TERMS, EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE AS TO ANY MATTER, INCLUDING BUT NOT LIMITED TO PERFORMANCE, SECURITY, NON-INFRINGEMENT OF THIRD PARTY RIGHTS, INTEGRATION, MERCHANTABILITY, QUIET ENJOYMENT, SATISFACTORY QUALITY OR FITNESS FOR ANY PARTICULAR PURPOSE. The provisions of Sections 4 and Section 5 will survive the termination of this agreement, howsoever caused, but this will not imply or create any continued right to use the Product after termination of this Agreement.

5. **LIMITATION OF LIABILITY.** EXCEPT FOR THE EXCLUSIVE REMEDY SET FORTH ABOVE AND AS OTHERWISE PROVIDED IN SECTION 3, IN NO EVENT WILL 3BUILT MOTORSPORTS OR ITS AFFILIATES OR SUPPLIERS BE LIABLE TO YOU FOR ANY LOSS, DAMAGES, CLAIMS OR COSTS WHATSOEVER INCLUDING ANY CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES, ANY LOST PROFITS OR LOST SAVINGS, ANY DAMAGES RESULTING FROM BUSINESS INTERRUPTION, PERSONAL INJURY OR FAILURE TO MEET ANY DUTY OF CARE, OR CLAIMS BY A THIRD PARTY, EVEN IF A 3BUILT REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS, DAMAGES, CLAIMS OR COSTS. THE FOREGOING LIMITATIONS AND EXCLUSIONS APPLY TO THE EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION. 3BUILT MOTORSPORTS' AGGREGATE LIABILITY AND THAT OF ITS AFFILIATES AND SUPPLIERS UNDER OR IN CONNECTION WITH THIS AGREEMENT WILL BE LIMITED TO THE AMOUNT PAID FOR THE PRODUCT, IF ANY. THIS LIMITATION WILL APPLY EVEN IN THE EVENT OF A FUNDAMENTAL OR MATERIAL BREACH OR A BREACH OF THE FUNDAMENTAL OR MATERIAL TERMS OF THIS AGREEMENT.
6. **INDEMNITY.** You agree to hold 3Built Motorsports harmless from any and all liabilities, losses, actions, damages, or claims (including all reasonable expenses, costs, and attorneys fees) arising out of or relating to any use of, or reliance on, the Product, including, without limitation reliance on a) batteries, b) range, c) installation, d) performance, and e) failure to exercise reasonable judgment. Nothing contained in this agreement limits 3Built Motorsports' liability to you in the event of death or personal injury resulting from 3Built Motorsports' negligence or for the tort of deceit (fraud). 3Built Motorsports is acting on behalf of its affiliates and suppliers for the purpose of disclaiming, excluding and limiting obligations, warranties and liability, but in no other respects and for no other purpose.
7. **GOVERNING LAW.** This agreement will be governed by and construed in accordance with the substantive laws in force in the State of California, if the Product is purchased when you are in the United States, Canada, or Mexico.
8. **GENERAL PROVISIONS.** If any part of this agreement is found void and unenforceable, it will not affect the validity of the balance of this agreement, which will remain valid and enforceable according to its terms. This agreement will not prejudice the statutory rights of any party dealing as a consumer. This agreement may only be modified by a writing signed by an authorized member of 3Built Motorsports. This is the entire agreement between 3Built Motorsports and you relating to the Product and it supercedes any prior representations, discussions, undertakings, communications, or advertising relating to the Product.



HE-2 RV INCLINOMETER / LEVELER INSTALLATION/USE INSTRUCTIONS


BY INSTALLING OR USING THIS PRODUCT YOU AGREE TO OUR “END USER AGREEMENT”. IT IS INCLUDED WITH THESE INSTRUCTIONS.

PLEASE BE SURE TO READ THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE USING THE HE-2

INCLUDED PARTS


- | | |
|------------------------------|----------------------|
| (1) HE-2 Inclinator | (1) Mounting bracket |
| (1) Micro USB charging cable | (1) 120V USB charger |

Please watch our video at: <https://heliosure.com/he-2/>



SET-UP

- 1) Use the USB charger and cable to fully charge the HE-2 Inclinator before use. The red light will illuminate while charging. The white/blue light will illuminate when complete.
- 2) While the unit is charging, measure the width and length of your RV's wheel spacing. You want the center-to-center spacing but it's usually easier to measure from the inside of one wheel to the outside of the other wheel as shown below. Measure in inches or centimeters and write the value down.



- 3) The Display has 15 different screens. **The screen number is shown at the top right of the Display.**
 - a. Screens 1-6 are for normal use. Screens 7-15 are for Setup Mode.
- 4) Once the HE-2 is charged, press the Power button for 2 seconds. The unit will turn on.
- 5) Use the UP arrow button to navigate to screen #7 “Admin Mode”

SET LENGTH

- 6) Press the ENTER button and you will be on screen #8 “Set Length”.
- 7) Press ENTER again to edit the length value.
- 8) Then press the UP or DOWN buttons to set the correct length that you measured in step #2.
- 9) Press ENTER one more time to exit the edit mode.

SET WIDTH

- 10) Press the UP arrow to navigate to screen #9 “Set Width”
- 11) Press ENTER to edit the width value.
- 12) Then press the UP or DOWN buttons to set the correct width that you measured in step #2.
- 13) Press ENTER one more time to exit the edit mode.

SET TIRE BLOCK HEIGHT

- 14) Press the UP arrow to navigate to screen #10 "Set Block Ht."
- 15) Press ENTER to edit the tire block height value.
- 16) Then press the UP or DOWN buttons to set the correct block height.
 - a. The unit of measure (inches or centimeters) must be the same as the length and width measurements entered on screens #8 and #9.
 - b. For interlocking blocks, do not measure the part that inserts into the other block.
- 17) Press ENTER one more time to exit the edit mode.
- 18) Wait 10 seconds for the unit to exit Admin Mode and save the values.

INSTALLATION

- 19) Find a suitable installation location for the HE-2. It must be within 45° of flat level to maintain accuracy.
- 20) Install the mounting bracket with double-sided tape or screws.
- 21) Make sure the HE-2 can be easily removed and installed into the bracket.

RV FLOOR TO INSTALLED POSITION CALIBRATION

- 22) Make sure the unit is ON.
- 23) Place the unit on the floor or other surface that is the one to be level when parked. Try to be accurate with the rotation of the HE-2 as it will affect accuracy. The FRONT arrow must point to the front of the RV.
- 24) Press the UP arrow to navigate to screen #7 "Admin Mode"
- 25) Press ENTER to get to menu #8
- 26) Press UP and navigate to screen #12 "Calibration, Level Surface"
- 27) Press ENTER for 2 seconds. A 3-second countdown timer will commence. At 0, the calibration will be performed. Do not move or bump the HE-2 during calibration. "Complete" will be shown when finished.
- 28) Now place the HE-2 back into the previously installed mounting bracket. (Step 19)
- 29) You should be on screen #13 "Calibration Installed Surface". If not, press the up or down arrows to navigate to menu #13.
- 30) Press ENTER for 2 seconds. A 3-second countdown timer will commence. At 0, the calibration will be performed. Do not move or bump the HE-2 during calibration. "Complete" will be shown when finished.
- 31) SETUP IS COMPLETE

USING THE INCLINOMETER

- 1) Press the power button below the Heliosure logo for 2 seconds. The unit will turn on.
- 2) 1 of 6 display screens will be shown. **The screen number is shown at the top right of the Display.**
 - a. #1 - **CUSTOMER** calibrated **HEIGHT**. This means it uses the information from steps #21-#29. The unit of measure is the same as was used in Length, Width, and Block Height.
 - b. #2 - **FACTORY** calibrated **HEIGHT**. Relies only on the factory calibration.
 - c. #3 - **CUSTOMER** calibrated **BLOCKS**. This means it uses the information from steps #21-#29. Unit of measure is Quantity of blocks.
 - d. #4 - **FACTORY** calibrated **BLOCKS**. Relies only on the factory calibration. Unit of measure is Quantity of blocks.
 - e. #5 - **CUSTOMER** calibrated **PITCH AND ROLL**. This means it uses the information from steps #21-#29. The unit of measure is angular Degrees.
 - i. Pitch shows back to front. Positive numbers mean the front is higher than the rear.
 - ii. Roll shows left to right. Positive numbers mean the right is higher than the left.
 - f. #6 - **FACTORY** calibrated **PITCH AND ROLL**. Relies only on the factory calibration.
 - i. Pitch shows back to front. Positive numbers mean the front is higher than the rear.
 - ii. Roll shows left to right. Positive numbers mean the right is higher than the left.
- 3) Press and hold the POWER button for 3 seconds to turn off the HE-2. It will also automatically power after a preset time. Programmable on screen #14.

OPTIONAL

- 1) Press ENTER if you'd like to **FREEZE** the display. This allows you to remove the display from the mounting bracket and use it outside when placing blocks. It eliminates the need to memorize how many blocks per wheel. Press ENTER again to unfreeze.
- 2) While on any display screen, pressing ENTER for 2 seconds will save that display screen (#1-6) as the default screen for each subsequent power-up.

These instructions are subject to change without notice.
SALES AND TECHNICAL SUPPORT E-MAIL: sales@heliosure.com
www.heliosure.com